

TMKB

T63

PRODUCT USER MANUAL


Specifications

Product Name: T63	Bluetooth: TMKB T63
Backlight: RGB	Material : Case-ABS, Keycaps-ABS
Battery: 3000 mAh	Optional Mode: Wired / Bluetooth / 2.4G
Key: 63 Keys	Interface Type: Type-C / Bluetooth / 2.4G
Size: 292.8×101×42mm	Product Weight: 640g±20g
Package Included: Keyboard, Type-C Cable, Keycaps Puller , User Manual, 2.4G Dongle	

If you have any problems or need assistance related to this product, please feel free to ask our customer service for help.
Email: customer@Kemove.com

Instruction for Using Fn Key


Bluetooth



- ① Set the switch of the back to bluetooth mode.
- ② Long press Fn+C/W/B, the light of C/W/B key blinks to turn on the Bluetooth pairing, and search "TMKB T63" to complete the connection pairing.
- ③ Short press Fn+C/W/B to switch to the connected Bluetooth device 1/2/3.

Instruction for Using Fn Key


Profile & Function



- Fn: check current configuration layer, system layout and Bluetooth channel.
- 1. Fn key pressed ,the lighting key(Q/W/E/R/T KEY) corresponded to the current configuration layer .
- 2. Fn key pressed, the lighting key (Z/X KEY) corresponded to the current system.
- 3. Fn key pressed, the lighting key(C/V/B KEY) corresponded to the current channel of Bluetooth.

Instruction for Using Fn Key


Profile & Function



- Fn+1 : F1
- Fn+2 : F2
- Fn+3 : F3
- Fn+Esc : `
- Fn+4 : F4
- Fn+5 : F5
- Fn+6 : F6
- Fn+Shift+Esc : ~
- Fn+7 : F7
- Fn+8 : F8
- Fn+9 : F9
- Fn+0 : F10
- Fn+~ : F11
- Fn+~+ : F12

Instruction for Using Fn Key


Profile & Function



- Fn+U : PrtSc
- Fn+J : Ins
- Fn+K : Del
- Fn+O : Pause
- Fn+P : Home
- Fn+~ : End
- Fn+~+ : PgUp
- Fn+~+ : PgDn

Instruction for Using Fn Key


Profile & Function



- Fn+Q : Profile 1
- Fn+W : Profile 2
- Fn+E : Profile 3
- Fn+R : Profile 4
- Fn+T : Profile 0
- Fn+Win : Win key locked / unlocked (Win key light change to white when locked, it follows current light mode when Win key is unlocked.)
- Fn+Spacebar : Fn key locked/unlocked (Fn key flashes red light when locked, it follows current light mode when Fn key is unlocked.)

Instruction for Using Fn Key


Multi-Media



- Fn+A : Play / Pause
- Fn+S : Previous song
- Fn+D : Next song
- Fn+F : Mute
- Fn+G : Volume down
- Fn+H : Volume up



Instruction for Using Fn Key

Lighting



- Fn+Backspace : Turn the light on / off
- Fn+Enter : Switch light colours
- Fn+~+ : Weaken light brightness
- Fn+~- : Change custom lighting
- Fn+~+ : Switch light modes
- Fn+~- : Speed down light effect
- Fn+~+ : Power saving mode
- Fn+~+ : Increase light brightness
- Fn+~- : Speed up light effect

Toggle switch & Indicator



- BT mode**
The switch set to BT mode, connect keyboard to BT device to use.
- 2.4G mode**
The switch set to 2.4G mode, plug the receiver into computer to use.
- Wired mode**
The switch set to wired mode, plug the cable into computer to use.
- Fn+N : 2.4G mode**
Turn on 2.4G mode
- Fn+right Alt : Battery status:**
● 0%~20% The spacebar key flashes red light
● 20%~80% The spacebar key flashes green light
● 80%~100% The spacebar key flashes blue light
- Fn+C/V/B : Bluetooth mode**
● Turn on BT1 mode
● Turn on BT2 mode
● Turn on BT3 mode